



Broadcaster	Service Name	LCN (dec)	Victoria																																South Australia										NSW																													
			Melbourne				Gippsland				Bendigo / Swan Hill				Goulburn Valley (Shepparton)				Upper Murray (Albury)				Western Victoria (Ballarat)				Mildura				Adelaide		Mt. Gambier		Riverland		Spencer Gulf		Eyre Peninsula (Port Augusta)		Broken Hill																																	
			ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID	ONID	NID	TSID	SID																
ABC	ABC1	2	1010	321B	0231		1010	3253	0233		1010	3253	0233		1010	3253	0233		1010	3253	0233		1010	3253	0233		1010	3253	0233		1010	3253	0233		1010	322F	0251		1010	3255	0253		1010	3255	0253		1010	3255	0253		1010	3255	0253		1010	3252	0223		1010	3252	0223													
	ABC News 24	24			0230				02B0				02B0				02B0				02B0				02B0				02B0				02D0				02D0				02D0				02D0				02A0																									
	ABC1	21			0233				02B3				02B3				02B3				02B3				02B3				02D3				02D3				02D3				02D3				02D3				02A3																									
	ABC2 / ABC4	22			0232				02B2				02B2				02B2				02B2				02B2				02D2				02D2				02D2				02D2				02A2																													
	ABC3	23			0234				02B4				02B4				02B4				02B4				02B4				02D4				02D4				02D4				02D4				02A4																													
	ABC Dig Music	200			0236				02B6				02B6				02B6				02B6				02B6				02D6				02D6				02D6				02D6				02A6																													
ABC Jazz	201			0237				02B7				02B7				02B7				02B7				02B7				02D7				02D7				02D7				02D7				02A7																														
SBS	SBS ONE	3	3202	3202	0310		3202	3202	0370		3202	3202	0370		3202	3202	0370		3202	3202	0370		3202	3202	0370		3202	3202	0370		3202	3202	0340		3202	3202	0390		3202	3202	0390		3202	3202	0390		3202	3202	0390		3202	3202	0390		3202	3202	0390		3202	3202	0390		3202	3202	0390		3202	3202	0390		3202	3202	0390	
	SBS ONE HD	30			0311				0371				0371				0371				0371				0371				0341				0391				0391				0391				0391				0391				0391				0391																	
	SBS VICELAND HD	31			0315				0375				0375				0375				0375				0375				0345				0395				0395				0395				0395				0395				0395				0395																	
	SBS VICELAND	32			0316				0376				0376				0376				0376				0376				0346				0396				0396				0396				0396				0396				0396																					
	SBS Food	33			0312				0372				0372				0372				0372				0372				0342				0392				0392				0392				0392				0392				0392																					
	NITV	34			0313				0373				0373				0373				0373				0373				0343				0393				0393				0393				0393				0393				0393																					
	SBS Arabic24	36			0314				0374				0374				0374				0374				0374				0344				0394				0394				0394				0394				0394				0394																					
	SBS Radio 1	37			31D				037D				037D				037D				037D				037D				034D				039D				039D				039D				039D				039D				039D																					
	SBS Radio 2	38			031E				037E				037E				037E				037E				037E				034E				039E				039E				039E				039E				039E				039E																					
	SBS Radio 3	39			031F				037F				037F				037F				037F				037F				034F				039F				039F				039F				039F				039F				039F																					
	SBS Chill	301			0320				0380				0380				0380				0380				0380				0350				03A0				03A0				03A0				03A0				03A0				03A0																					
	SBS Radio 1	302			0322				0382				0382				0382				0382				0382				0352				03A2				03A2				03A2				03A2				03A2				03A2																					
	SBS Radio 2	303			0323				0383				0383				0383				0383				0383				0353				03A3				03A3				03A3				03A3				03A3				03A3																					
	SBS Radio 3	304			0324				0384				0384				0384				0384				0384				0354				03A4				03A4				03A4				03A4				03A4				03A4																					
	SBS Arabic24	305			0325				0385				0385				0385				0385				0385				0355				03A5				03A5				03A5				03A5				03A5				03A5																					
SBS PopDesi	306			0326				0386				0386				0386				0386				0386				0356				03A6				03A6				03A6				03A6				03A6																										
SBS Chill	307			0327				0387				0387				0387				0387				0387				0357				03A7				03A7				03A7				03A7				03A7				03A7																						
SBS PopAsia	307			0327				0387				0387				0387				0387				0387				0357				03A7				03A7				03A7				03A7				03A7				03A7																						
Southern Cross	Nine + Market name	5					320C	329A	0801		320C	329C	0803		320C	329D	0804		320C	329E	0805		320C	329B	0802																																																	
	9HD + Market Name	50							08C1				08C3				08C4				08C5				08C2																																																	
	Nine + Market name	51							08A1				08A3				08A4				08A5				08A2																																																	
	9Gem	52							0821				0823				0824				0825				0822																																																	
	9Go!	53							0841				0843				0844				0845				0842																																																	
	9Life	54							08E1				08E3				08E4				08E5				08E2																																																	
	SBN	55							0861				0863				0864				0865				0862																																																	
Aspire	56							0881				0883				0884				0885				0882																																																		
Prime Television	PRIME7 + Market Name	6					3283	3283	099D		3283	3283	099D		3283	3283	09A1		3283	3283	09A1		3283	3283	099D		3283	3283	099D																																													
	PRIME7 HD + Market Name	60							0952				0950				094C				094D				094E																																																	
	PRIME7 + Market Name	61							0988				0974				0960				096A				0960																																																	
	7TWO + Market Name	62							0989																																																																	