Free TV Australia DTTB SI Register — **Transport Stream Service Information for Television Market Area** — **All values are hexadecimal**

Issue 12 **Date : November 2018**

FreeTV Australia

NSW | **A.C.T.**

Broadcaster	Service Name	LCN (dec)	Sydney				Central Coast (see Note 1)				Newcastle / Upper Hunter				Mid North Coast (Taree)				Northern Rivers (Coffs Harbour)				Richmond Tweed (Lismore)				Inland Northern NSW (Tamworth)				South West Slopes (Wagga)				C. W. Slopes / Central Tablelands (Orange)				Illawarra (Wollongong)				South Coast				Griffith / MIA				Canberra			
			O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID	O/NID	NID	TSID	SID
ABC			1010	3211	0221		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3252	0223		1010	3251	0211	
	ABC1	2				0221				02A1				02A1				02A1				02A1				02A1				02A1				02A1				02A1				02A1				02A1				02A1				0211
	ABC News 24	24				0220				02A0				02A0				02A0				02A0				02A0				02A0				02A0				02A0				02A0				02A0				02A0				0210
	ABC1	21				0223				02A3				02A3				02A3				02A3				02A3				02A3				02A3				02A3				02A3				02A3				02A3				0213
	ABC2 / ABC4	22				0222				02A2				02A2				02A2				02A2				02A2				02A2				02A2				02A2				02A2				02A2				02A2				0212
	ABC3	23				0224				02A4				02A4				02A4				02A4				02A4				02A4				02A4				02A4				02A4				02A4				02A4				0214
	ABC Dig Music	200				0226				02A6				02A6				02A6				02A6				02A6				02A6				02A6				02A6				02A6				02A6				02A6				0216
	ABC Jazz	201				0227				02A7				02A7				02A7				02A7				02A7				02A7				02A7				02A7				02A7				02A7				02A7				0217
SBS			3202	3202	0300		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350		3202	3202	0350	
	SBS ONE	3				0301				0351				0351				0351				0351				0351				0351				0351				0351				0351				0351				0351				0351
	SBS ONE HD	30				0306				0355				0355				0355				0355				0355				0355				0355				0355				0355				0355				0355				0355
	SBS VICELAND HD	31				0303				0356				0356				0356				0356				0356				0356				0356				0356				0356				0356				0356				0356
	SBS VICELAND	32				0302				0352				0352				0352				0352				0352				0352				0352				0352				0352				0352				0352				0352
	SBS Food	33				0304				0353				0353				0353				0353				0353				0353				0353				0353				0353				0353				0353				0353
	NITV	34				0305				0354				0354				0354				0354				0354				0354				0354				0354				0354				0354				0354				0354
	SBS Arabic24	36				030D				035D				035D				035D				035D				035D				035D				035D				035D				035D				035D				035D				035D
	SBS Radio 1	37				030E				035E				035E				035E				035E				035E				035E				035E				035E				035E				035E				035E				035E
	SBS Radio 2	38				030F				035F				035F				035F				035F				035F				035F				035F				035F				035F				035F				035F				035F
	SBS Chill	39				0310				0360				0360				0360				0360				0360				0360				0360				0360				0360				0360				0360				0360
	SBS Radio 1	301				0311				0361				0361				0361				0361				0361				0361				0361				0361				0361				0361				0361				0361
	SBS Radio 2	302				0312				0362				0362				0362				0362				0362				0362				0362				0362				0362				0362				0362				0362
	SBS Radio 3	303				0313				0363				0363				0363				0363				0363				0363				0363				0363				0363				0363				0363				0363
	SBS Arabic24	304				0314				0364				0364				0364				0364				0364				0364				0364				0364				0364				0364				0364				0364
	SBS PopDesi	305				0315				0365				0365				0365				0365				0365				0365				0365				0365				0365				0365				0365				0365
	SBS Chill	306				0316				0366				0366				0366				0366				0366				0366				0366				0366				0366				0366				0366				0366
	SBS PopAsia	307				0317				0367				0367				0367				0367				0367				0367				0367				0367				0367				0367				0367				0367
Seven Network			1013	3214	0502		1013	3214	0502																																													
	7 + Market name	7				0520				0520																																												
	7HD + Market name	70				0524				0524																																											
	7 + Market name	71				0521				0521																																											
	7TWO + Market name	72				0522				0522																																											
	7mate + Market name	73				0523				0523																																											
	7food network	74				0527				0527																																											
	7flix + Market name	76				0525				0525																																											
	RACING.COM	78				0528				0528																																											
Nine Network			1012	3213	0420		1012	3213	0420																																												
	Channel 9 Marketname	9				0421				0421																																											
	Channel 9 Marketname	91				0426				0426																																											
	9HD	90				0422				0422																																											
	9GEM	92				0427				0427																																											
	9Life	94				0424				0424																																											
	Your Money	95				0425				0425																																											
	9Go!	99				0423				0423																																											
	9Go!	93				0428				0428																																											
Network Ten			1014	3215	0602		1014	3215	0602																																												
	10 Bold	1				0621				0621																																											
	10	10				0625				0625																																											
	10 HD	13				0624				0624																																											
	10 Bold	12				0627				0627																																											
	10 Peach	11				0628				0628																																											
	TVSN	14				0626				0626																																											
	SpreeTV	15				0629				0629																																											
Community TV	See Note 2																		